

Environmental Health and Safety 2220 Circle Drive Cleveland, Ohio 44106 P: (216) 368-2906

> F: (216) 368-2236 cwruehs@case.edu

## Copper (Cu-64)

Half Life: 12.7 hours

Radiation: Beta, Gamma and X-rays

Shielding: Minimum of 6 mm lead. Bremsstrahlung may be created

and require additional shielding

**Dosimetry**: Body and ring badges when handling

**Detection/Measurement**: GM pancake probe. Low energy gamma counter and wipe tests

## **General Precautions:**

- Maintain your occupational exposure to radiation As Low As Reasonably Achievable [ALARA]
- All persons handling radioactive material must be properly trained by EHS prior to handling and are listed as a rad worker by EHS department
- Plan experiments accordingly to minimize external exposure by reducing exposure time, using shielding and increasing your distance from the radiation source
- Monitor yourself and the work area during and after each use of radioactive material
- Use the smallest amount of radioisotope possible to minimize radiation dose and radioactive waste
- Keep an accurate inventory of all radioactive material including records of all receipts, transfers and disposal – contact EHS for any disposal needs including liquid waste
- Perform and record lab surveys as needed (monthly and post experiment)

 Avoid generating mixed waste (combinations of radioactive, biological and chemical waste)

## **Special Precautions:**

- Store Cu-64 behind adequate lead (Pb) shielding (minimum of 2 inches lead)
- Use tools to indirectly handle unshielded sources and potentially contaminated containers - no direct hand contact
- Ensure that an appropriate, operational survey meter is present in the work area and turned on whenever Cu-64 is handled to immediately detect contamination
- Shield waste containers as needed to maintain accessible dose rate ALARA

## Safe Lab Practices:

- Disposable gloves, lab coats, and safety glasses are the minimum PPE required when handling radioactive material
- Remove and discard potentially contaminated PPE prior to leaving the lab area where radioactive material is used
- Cover all lab bench tops where radioactive material is handled with plastic-backed absorbent paper change as needed
- Handle radioactive solutions in trays large enough to contain the material in the event of a spill
- Never eat, drink, smoke, handle contact lenses, apply cosmetics, or take medicine in the lab - keep food, drinks, and cosmetics out of the lab entirely
- Never pipette by mouth
- Never store food and beverages in refrigerators/freezers used for storing radioisotopes – ensure that isotopes are secured at all times
- Avoid any skin contact with skin-absorbable solvents containing radioactive materials
- Fume hoods and biological safety cabinets for use with nonairborne radioactive material must work properly and be inspected annually by the EHS department
- Do not take any radioactive material off site or use in any ways not approved by the Radiation Safety Officer