



**CASE  
WESTERN  
RESERVE  
UNIVERSITY**

Environmental Health and Safety  
2220 Circle Drive  
Cleveland, Ohio 44106  
P: (216) 368-2906  
F: (216) 368-2236  
[cwruehs@case.edu](mailto:cwruehs@case.edu)

---

## **Gallium (Ga-68)**

---

**Half Life:** 68 minutes

**Radiation:** Beta, gamma and X-rays

**Shielding:** 20mm lead. Bremsstrahlung may be created and require additional shielding

**Dosimetry:** Body and ring badges. Urine assays may be required after spills or contamination incidents.

**Detection/Measurement:** GM with pancake probe. Wipe tests

### **General Precautions:**

- Maintain your occupational exposure to radiation As Low As Reasonably Achievable [ALARA]
- All persons handling radioactive material must be properly trained by EHS prior to handling and are listed as a rad worker by EHS department
- Plan experiments accordingly to minimize external exposure by reducing exposure time, using shielding and increasing your distance from the radiation source
- Monitor yourself and the work area during and after each use of radioactive material
- Use the smallest amount of radioisotope possible to minimize radiation dose and radioactive waste
- Keep an accurate inventory of all radioactive material including records of all receipts, transfers and disposal – contact EHS for any disposal needs including liquid waste
- Perform and record lab surveys as needed (monthly and post experiment)

- Avoid generating mixed waste (combinations of radioactive, biological and chemical waste)

### **Special Precautions:**

- Store Ga-68 behind 18 mm lead shielding when working with. Use tools to indirectly handle unshielded sources and potentially contaminated containers - no direct hand contact
- Ensure that an appropriate, operational survey meter is present in the work area and turned on whenever Ga-68 is handled to immediately detect contamination
- Shield waste containers as needed to maintain accessible dose rate ALARA

### **Safe Lab Practices:**

- Disposable gloves, lab coats, and safety glasses are the minimum PPE required when handling radioactive material
- Remove and discard potentially contaminated PPE prior to leaving the lab area where radioactive material is used
- Cover all lab bench tops where radioactive material is handled with plastic-backed absorbent paper – change as needed
- Handle radioactive solutions in trays large enough to contain the material in the event of a spill
- Never eat, drink, smoke, handle contact lenses, apply cosmetics, or take medicine in the lab - keep food, drinks, and cosmetics out of the lab entirely
- Never pipette by mouth
- Never store food and beverages in refrigerators/freezers used for storing radioisotopes – ensure that isotopes are secured at all times
- Avoid any skin contact with skin-absorbable solvents containing radioactive materials
- Fume hoods and biological safety cabinets for use with non-airborne radioactive material must work properly and be inspected annually by the EHS department
- Do not take any radioactive material off site or use in any ways not approved by the Radiation Safety Officer